


Lever Wash Basin Taps

INSTALLATION INSTRUCTIONS




Stock Code
23196CH

Please read all instructions before installation and leave this document with the end user for future reference as it contains important warranty information


Important Information

This product must be installed in compliance with Water Bylaw Regulations. Isolating and non-return valves should be fitted (not supplied). If you are unsure, please obtain the advice of a professional plumber before attempting any work. Minimum working pressure is 0.2 bar.


Parts Provided



Dimensions



Reference	Description	Quantity
A	Tap	2
B	Washer Gasket	4
C	Back Nut	2



1. Check the water use requirements under local regulations.
2. Remove the back nut (C) leaving the washer gasket (B) on the tap tail adjacent to the tap body.
3. Place the tap (A) together with washer gasket (B) on the fitting surface of the basin. Note: the hot tap indicated with the colour red is normally fitted on the left when viewed from the front.
4. Position the tap as required. Whilst holding the tap in place, insert the second rubber gasket to the underside, screw the back nut (C) onto the tap (A) and tighten. Do not over-tighten as this may damage the mounting surface.
5. Repeat steps 2-4 for the other tap.
6. Connect the water supply to the taps.
7. For on and off turn the handles (D).

Commissioning

Open isolating valves and check for leaks.

Turn cold tap on.

Allow a few minutes of running and then repeat for the hot water.

Turn off and check for further leaks.

Cleaning and Care

Clean using warm, soapy water only.

Do not use scourers or abrasive cleaners which may affect the surface finish.

Never use corrosive acidic or alkaline cleaning materials on fittings or surfaces.

Always flush cleaning materials away with copious amounts of water and wipe down to dry.

Contact Us

AKW
Life Made Better

Orders & Quotes

01905 823 299
orders@akw-ltd.co.uk

General Enquiries

01905 823 298
sales@akw-ltd.co.uk

Technical Enquiries

01905 560 219
tech@akw-ltd.co.uk

Kitchen Enquiries

01905 823 262
kitchens@akw-ltd.co.uk

Fax

01905 823 297

AKW

Pointon Way, Hampton Lovett
Droitwich Spa, WR9 0LR

www.akw-ltd.co.uk
orders.akw-ltd.co.uk

Follow us on Social:



Warranty

Warranty applies only to manufacturing or material defects, conditional on the one-time correct installation of the product. It does not apply to:

- Inappropriate use or accidental damage.
- Damage or defects that result from incorrect installation.
- Lack of maintenance including the build up of grime or damage resulting from inappropriate cleaning.
- Damage or defects that result from repairs or modifications undertaken by unauthorised persons.
- General wear and tear through usage and does not apply to surface finishes.

Warranty period starts from the date of installation. See the T&Cs on our website for further information.

Select 1 of 2 ways to activate your warranty



1. Scan using your Smart Device



2. Visit Online

akw-ltd.co.uk/warranty-information

What to do if something goes wrong?

In the event that you encounter a problem with this product, follow the trouble shooting guide if applicable, then contact your local installer. If the issue is still unresolved, contact AKW Technical Enquiries who will provide further advice and arrange for a maintenance engineer to visit if necessary. None of the foregoing affects your statutory rights.