






Spare Parts / Ersatzteile / Pièces de recharge / Pezzi di Ricambio / Piezas de requesto /
 Parte de reposição / Reserveonderdelen / Reservdelar / Reservedeler / Varaosat /
 Vraosat / Varahlutir / Ανταλλακτικά / Yedek Parçalar / Náhradní díly / Náhradné diely /
 Nadomestni deli / Резервни части / Запчасти / Części Zapasowe / Piese de schimb
 / Rendelhető alkatrészek / Запасні частини / Reservni delovi / Резервни делови /
 Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezervju daļu

XX = RO, SI, XG



Pos.	Part No.
1	A 861 658 XX
2	A 861 659 NU
3	A 861 660 NU
4	A 861 661 NU
5	A 861 640 XX
6	A 861 631 XX
7	A 861 632 XX
8	BD 581 XX
9	A 861 628 XX
10	A 861 630 XX
11	BD 580 XX
12	A 861 629 XX
13	BE 175 XX
14	B 961 890 XX



Ideal Standard






**CERAFLOW ALU +
BD 585 ..**

0923 / A 869 051



Ideal Standard International NV
 Corporate Village - Gent Building
 Da Vincilaan 2
 1935 Zaventem
 Belgium

www.idealstandardinternational.com



	P	bar		MAX. 10		5		Q	(3 bar)
	T	°C		MAX. 80		65			
						55		8	12

